



Best Regards,

Our pedal designer is Kenny Segal. Kenny hopes you try all of our Snarling Dogs stomp boxes and wahs. Check out our website for info on our latest pedal designs!

Snarling Dogs wahs
Snarling Dogs effects
Snarling Dogs strings

Check out our website www.snarlingdogs.com to see:

This Snarling Dogs Bawl Buster Bass Wah was designed and manufactured to give you many years of trouble-free operation. Please read this manual carefully to learn how to use all the controls and the features of the pedal. In the event that you pedal does not function properly, please read the trouble shooting section before contacting us.

Thank you for purchasing the
Snarling Dogs Bawl Buster Bass Wah™!

LIMITED WARRANTY

Try our entire line of snarling wah pedals and stomp boxes:



BAWL BUSTER™

Moan-to-the-Bone Bass Wah

SNARLING INSTRUCTION MANUAL



D'Andrea Inc.
115 Eileen Way, Syosset, NY 11791 USA
Ph: 516-496-2200 • Fax: 516-496-2425
email: customerservice@dandrainc.com
web: www.snarlingdogs.com • www.dandreapicks.com
Snarling Dogs® is a registered trademark of D'Andrea Inc.


This Snarling Dogs effects unit is warranted to the original purchaser by D'Andrea Inc. for a period of one (1) year from the date of sale. If returned to the retailer within that time, D'Andrea Inc., in its sole discretion, may choose to (1) replace the entire unit with another new or reconditioned unit; or (2) to replace any defective part which, upon inspection by an authorized service center, proves to have failed in the ordinary course of use due to defects in material or workmanship. D'Andrea Inc.'s entire liability, and purchaser's exclusive remedy, is the replacement or repair of the Product as described herein. D'Andrea Inc. shall not be liable for any personal injury, property damage, or any incidental or consequential damages of any kind resulting from defects, malfunctions misuse, improper installation or operation, incorrect voltage, or alteration of the product. This warranty does not apply to failure of the Product due to misuse, abuse, accident, neglect, mishandling, improper repair, repair attempted by anyone other than an authorized service agent, operation under any conditions other than those recommended or at voltages other than the voltage indicated on the unit, or wear from ordinary use. Any attempts at repair by unauthorized persons or purchaser will render this warranty void.

Warranty service is only available by first contacting D'Andrea Inc. for a Return Authorization Number and then sending the unit, postage prepaid, with the original sales receipt. This warranty is available in the USA only.

Service Center
Jersey Technical
106 Eigel Ave.
Middlsex, NJ 08846

IMPORTANT!

If you will be powering your Snarling Dogs pedal with a 9 volt adapter, it is important for you to use a SOUND-SENSE regulated adapter or other regulated adapter. Non-regulated adapters will cause the unit to be noisy and may cause harm to the unit. Your dealer can purchase SOUND SENSE Adapters through D'Andrea Inc. If your dealer does not carry these, alkaline batteries offer extended life, and may enhance the sound qualities of the pedal.



GETTING STARTED

1. To install a battery, simply unscrew the battery access plate on the bottom of the unit. Make sure the battery clips are securely attached to the battery.
2. For cable hook-up, plug your guitar cable into the 1/4 inch jack marked INPUT.
3. Plug the cable leading to your amplifier into the 1/4 inch jack marked OUTPUT.
4. To activate the pedal, depress the footswitch. When the pedal is activated, the Snarling Dogs eyes will light up. Depressing the switch again will bypass the pedal's signal.

Wah Controls

The Bawl Buster Bass Wah has a volume control on the right side of the wah as you look at it from the heel position. Depending on where you have the volume of your guitar and amp set, you can adjust the volume control on your wah so that it is louder or softer than your current volume once the pedal is turned on. For instance, you may wish to use the wah during your solo. If so, you would typically want the volume to increase once you activate the pedal. Predetermine the Wah volume setting that will provide the desired increase, and leave the volume control in that position. You will notice another control on the left side of the pedal as you look at the pedal from the heel position. This is the wah selector. We have set this selector to give you the wah tones described below.

Important!

You can also use your Bawl Buster Wah as a Frequency Filter by activating the pedal, finding a frequency within the sweep of the footpad that you particularly like and leaving the footpad in that position.

1. WAH Selector:

- a) **White Room Wah** - produces a rich, bassy, creamy wah.
- b) **Voo Doo** - This is a midrange crunch wah.
- c) **Shaft** - This is the classic "waka-chu-waka-chu-waka" wah sound made famous in the movie of the same name. Great for bright, funky wah.

2. WAH Volume - Allows adjustment to output volume of wah pedal.

Trouble Shooting

Symptom	Possible Cause	Remedy
No sound	Dead battery?	Replace battery
No sound	Is there a broken cable?	Check cables and replace if broken
No sound	Is 1/4" cable(s) not pushed all the way in?	Push cable(s) all the way in
No sound	Is instrument cable attached to "in" jack and amp cable attached to "out" jack?	Reconnect cables properly
No sound	Adapter not plugged in	Make sure adapter is properly plugged into working wall outlet and pedal
Distorted or poor sound quality	Weak/dead battery?	Replace battery
LEDS/eyes not lighting up	Weak/dead battery?	Replace battery