

Snarling Dogs™ Chord Computer Model BG-1

OPERATING INSTRUCTIONS

To Display a Chord:

1. Press ON
2. Select note name for chord (C,D,E,F,G,A or B)
3. Select flat or sharp, if either is desired
4. Select MIN, AUG, DIM if one of these is desired. MAJ will automatically be displayed if none of these three has been selected.
5. Select 6th, 7th or 9th if desired.

INVERSIONS After you have displayed the chord in root position, pressing the INV button will display the first inversion of that chord. Pressing the INV button a second time will display the second inversion of that chord and so on. After the final inversion has been displayed you can return the chord to root position by pressing INV one more time.

SCALES After you have displayed the chord in root position, pressing the SCALE button will display the complete scale for that note. Note that the CHORD COMPUTER will ignore the 6th 7th or 9th when displaying the scale. (Example: selecting an Am7 chord and then pressing the SCALE button produces the harmonic minor scale.)

TO TRANSPOSE You can transpose a chord or scale up or down in half steps by pressing the SHARP or FLAT button.

OFF/CLEAR If nothing but the outline of the keyboard is showing on the display, pressing the OFF/CLEAR button will turn the unit off. If any chord or scale is on the display, then pressing the OFF/CLEAR will clear the display and the CHORD COMPUTER is ready for you to enter the next chord or scale.

AUTOMATIC SHUT-OFF The unit automatically shuts off 4 minutes after the last user command.



Registration Card

(US Residents Only)

Must be filled out and returned with copy of sales receipt for warranty to be valid.

1. Mr. ___ Mrs. ___ Ms. ___ Miss ___
First Name _____ Last Name _____
Address _____ Apt _____
City _____ State _____ Zip _____
2. Phone Number (____) _____ - _____
____ Please check if you would like to receive product updates and information.
3. Email Address _____
4. Model Number _____ Serial Number _____
5. Price Paid \$ _____ Date Purchased ____/____/____
6. Store Name _____ Location _____
7. Age (check one) 10 - 19 ___ 20 - 29 ___ 30 - 39 ___ 40 - 49 ___ 50 - 59 ___ 60+ ___
8. Which best describes your income? Under \$15,000 ___ \$15,000 - \$24,999 ___ \$25,000 - \$49,999 ___ \$50,000+ ___
9. Primary Instrument (check one) Electric Guitar ___ Acoustic Guitar ___ Electric Bass ___ Acoustic Bass ___
Keyboards ___ Piano ___ Drums ___ Other _____
10. Additional Instruments Electric Guitar ___ Acoustic Guitar ___ Electric Bass ___ Acoustic Bass ___
Keyboards ___ Piano ___ Drums ___ Other _____
11. Musical Style (check all that apply) Rock ___ Jazz ___ Blues ___ Country ___ Alternative ___ Top 40 ___ Classical ___
Latin ___ Other _____
12. Magazines Read (check all that apply) Guitar Player ___ Guitar World ___ Guitar One ___ Bass Player ___
Bass Frontiers ___ Bassics ___ Keyboard Player ___ Other _____
13. Number of musical instrument or accessory purchases in last year? 1 ___ 2 - 4 ___ 5 - 9 ___ 10+ ___
14. Dollar amount of purchases on musical instruments in last year? Less than \$100 ___ \$101 - \$299 ___
\$500 - \$999 ___ \$1000+ ___
15. I heard about Snarling Dogs from? (check all that apply) Ad ___ Friend ___ Sales Person ___
Magazine Review ___ In store display ___ www.snarlingdogs.com ___ Other _____
16. Comments and suggestions _____

Cut Here. Retain the bottom section for your records.

SNARLING DOGS^a Limited Warranty

This Snarling Dogs chord computer ("Product") is warranted to the original purchaser by D'Andrea Inc. for a period of one (1) year from the date of sale. If returned to the retailer within that time, D'Andrea Inc., in its sole discretion, may choose to (1) replace the entire Product with another new or reconditioned Product; or (2) to replace any defective part which, upon inspection by an authorized service center, proves to have failed in the ordinary course of use due to defects in material or workmanship.

If defective, D'Andrea Inc.'s entire liability, and purchaser's exclusive remedy, is the replacement or repair of the Product as described herein. D'Andrea Inc. shall not be liable for any personal injury, property damage, or any incidental or consequential damages of any kind resulting from defects, malfunctions misuse, improper installation or operation, incorrect voltage, or alteration of the Product.

This warranty does not apply to failure of the Product due to misuse, abuse, accident, neglect, mishandling, improper repair, repair attempted by anyone other than an authorized service agent, operation under any conditions other than those recommended or at voltages other than the voltage indicated on the unit, or wear from ordinary use. Any attempts at repair by unauthorized persons or purchaser will render this warranty void. This warranty does not cover batteries or cases.

Warranty service is only available by first contacting D'Andrea Inc. for a Return Authorization Number and then sending the Product, postage prepaid, with the original sales receipt. This warranty is available in the USA only.

D'Andrea Inc.

115 Eileen Way, Syosset, NY 11791
Phone: (516) 496-2200 Fax: (516) 496-2425
email: customerservice@dandreainc.com
www.snarlingdogs.com

D'Andrea Inc.

115 Eileen Way, Syosset, NY 11791
Phone: (516) 496-2200 Fax: (516) 496-2425
email: customerservice@dandreainc.com
www.snarlingdogs.com

FIRST
CLASS
POSTAGE
HERE

D'Andrea Inc.
115 Eileen Way
Syosset, NY 11791 USA

Cut Here. Retain the bottom section for your records.