



Best Regards,

Our pedal designer is Kenny Segall. Kenny hopes you try all of our Snarling Dogs stomp boxes and wahs. Check out our website for info on our latest pedal designs!

Snarling Dogs wahs
Snarling Dogs effects
Snarling Dogs strings


Check out our website www.snarlingdogs.com to see:

This Snarling Dogs Mold Spore Wah™ was designed and manufactured to give you many years of trouble-free operation. Please read this manual carefully to learn how to use all the controls and the features of the pedal. In the event that you pedal does not function properly, please read the trouble shooting section before contacting us.

Thank you for purchasing the
Snarling Dogs Mold Spore Wah™
with THMS!



Try our entire line of snarling wah pedals and stomp boxes:



WHINE-O™ WAH PLUS

SUPER BAWL™ WHINE-O WAH

FIRE BAWL™ WAH

BAWL BUSTER™ WAH

BLUES BAWLS™

EROGENOUS MOAN™

WONDER™ WAH

MOLD SPORE™

VERY-TONE™ DOG

BLACK DOG™

TWEED E. DOG™

BLUE DOG™

LIMITED WARRANTY

This Snarling Dogs effects unit is warranted to the original purchaser by D'Andrea Inc. for a period of one (1) year from the date of sale. If returned to the retailer within that time, D'Andrea Inc., in its sole discretion, may choose to (1) replace the entire unit with another new or reconditioned unit; or (2) to replace any defective part which, upon inspection by an authorized service center, proves to have failed in the ordinary course of use due to defects in material or workmanship.

If defective, D'Andrea Inc.'s entire liability, and purchaser's exclusive remedy, is the replacement or repair of the Product as described herein. D'Andrea Inc. shall not be liable for any personal injury, property damage, or any incidental or consequential damages of any kind resulting from defects, malfunctions misuse, improper installation or operation, incorrect voltage, or alteration of the product.

This warranty does not apply to failure of the Product due to misuse, abuse, accident, neglect, mishandling, improper repair, repair attempted by anyone other than an authorized service agent, operation under any conditions other than those recommended or at voltages other than the voltage indicated on the unit, or wear from ordinary use. Any attempts at repair by unauthorized persons or purchaser will render this warranty void.

Warranty service is only available by first contacting D'Andrea Inc. for a Return Authorization Number and then sending the unit, postage prepaid, with the original sales receipt. This warranty is available in the USA only.


Service Center
Jersey Technical
106 Eigel Ave.
Middlesex, NJ 08846



D'Andrea Inc.
115 Eileen Way, Syosset, NY 11791 USA
Ph: 516-496-2200 • Fax: 516-496-2425
email: customerservice@dandrea.com
web: www.snarlingdogs.com • www.dandreapicks.com
Snarling Dogs® is a registered trademark of D'Andrea Inc.

MOLD SPORE™
PSYCHOSCUMATIC WAH *With THMS*
*True Hard Mechanical Bypass Switch

SNARLING DOGS INSTRUCTION MANUAL



IMPORTANT!

If you will be powering your Snarling Dogs pedal with a 9 volt adapter, it is important for you to use a SOUND-SENSE regulated adapter or other regulated adapter. Non-regulated adapters will cause the unit to be noisy and may cause harm to the unit. Your dealer can purchase SOUND SENSE Adapters through D'Andrea Inc. If your dealer does not carry these, alkaline batteries offer extended life, and may enhance the sound qualities of the pedal.

GETTING STARTED

1. To install a battery, simply unscrew the battery access plate on the bottom of the unit. Make sure the battery clips are securely attached to the battery.
2. For cable hook-up, plug your guitar cable into the 1/4 inch jack marked INPUT.
3. Plug the cable leading to your amplifier into the 1/4 inch jack marked OUTPUT.
4. To activate the pedal, depress the footswitch. When the pedal is activated, the Snarling Dogs eyes will light up. Depressing the switch again will bypass the pedal's signal.

Mold Spore Controls

1. **WAH Selector** - a) White Room - Rich, bassy, "Creamy" wah tone.
b) Voo Doo - Midrangy, crunchy wah tone.
c) Shaft - Classic "Waka - Chu - Waka - Chu - Waka" wah sound. Bright, funky tone.
2. **WAH Volume** — Allows adjustment to output volume of wah pedal.
3. **Hi / Lo Tone Contour** — Overall tone contour for Mold Spore effect. Quickly sets Hi EQ or Low EQ on the Mold Spore Effect.
4. **Mold Spore Switch** — On/Off - Turns on the Mold Spore Ring Modulator.
5. **Psychoscumation Control (Insanity Control)** — This knob selects how much Mold (Ring - Modulation) is applied to your sound. It is a good idea to start with this knob at its minimum setting. (Maximum setting on this control may cause Brain Damage).
6. **Straight Jacket Volume** — This knob allows you to adjust how much Mold effect is blended with your Guitar/WAH sound.
7. **Freakwincy Sweep Control** — Allows manual adjustment of the Mold Sweep Range. If you have a favorite Mold Spore Sweep Range you like, just set this control and leave it in the position. The (#8) Freak Sweep Switch must be out for this knob to be ACTIVE.
8. **Freak Sweep Switch** — When activated (IN), This switch allows the above mentioned, "Freakwincy Sweep Control," to be activated by the Foot Pedal itself. NOTE: When selected (IN), this switch de-activates the Freakwincy Sweep Control Knob.

A. On/Off Switch — TMHBS

The importance of the TMHBS is that it allows the PURE guitar signal to be heard when the pedal is in the off position. Unlike electronic switching, or standard mechanical switching, with our TMHBS, you will not experience any of the "tone soak" you experience with other pedals. At the same time, you will still have the convenience of the Snarling Dogs LED eyes alerting you when the pedal is on or off.

The importance of TMHBS becomes especially important when you have a chain of effects. Without TMHBS, each pedal in the chain will soak up a portion of your original signal. The more pedals in your chain, the more your original tone will be diminished.

Trouble Shooting

Symptom	Possible Cause	Remedy
No sound	Dead battery?	Replace battery
No sound	Is there a broken cable?	Check cables and replace if broken
No sound	Is 1/4" cable(s) not pushed all the way in?	Push cable(s) all the way in
No sound	Is instrument cable attached to "in" jack and amp cable attached to "out" jack?	Reconnect cables properly
No sound	Adapter not plugged in	Make sure adapter is properly plugged into working wall outlet and pedal
Distorted or poor sound quality	Weak/dead battery?	Replace battery
LEDs/eyes not lighting up	Weak/dead battery?	Replace battery